

S-3602F/M/D/B/J/V/I/C Adapter/Charger for DV Battery

Ver: V1.0.0V01

# **USER MANUAL**

**SWIT Electronics Co., Ltd.** 

Tel: +86-25-85805753 Fax: +86-25-85805296 http://www.swit.cc Email:contact@swit. CC

### Characteristics

- 2-channel simultaneous charging;
- ◆ 4-level LED charging indicators;
- ◆ 2-channel simultaneous adapting output.

#### Caution

- 1.Only work in the temperature between 0°C~40°C
- 2. Keep the terminals clean and ensure the reliable connection.
- 3.Do not cover the cooling vent.
- 4. Never try to open the product.
- 5.Do not touch water or use it in wet environment.
- 6.Do not use metal or other conductors to touch the inside of the charger.

### **Compatible Batteries**

**S-3602F**: SWIT S-8970/8770; SONY NP-F970/770/550 **S-3602M**: SWIT S-8M71/8M91; SONY QM71/QM91


**S-3602D**: SWIT S-8D58/8D62; Panasonic CGA-D54/D28,VW-VBD58

S-3602B: SWIT S-8BG6; Panasonic VW-VBG6

**\$-3602J**: SWIT S-8428; JVC V428U **\$-3602V**: SWIT S-8823; JVC BN VF823 **\$-3602I**: SWIT S-8I50; JVC SSL-JVC50 **\$-3602C**: SWIT S-8945; Canon BP-930/945


### Charging

- Connect with power lead, the charger is automatically switched on.
- 2. Mount the compatible batteries onto the charging slot, and the LED charging indicator will start to flash and indicates the current capacity of each battery. (25%,50%, 75% and 100%)
- 3. When the battery is fully charger, all the 4 LEDs will light on and stop flashing.



## Adapting output

- 1. There are two 5.5mm pole DC output sockets: Primary output and Sencondary output.
- 2.Connect the adaptor power lead into DC socket, and the Adaptor indicator will lights on.
- 3.The two channels output simultaneously and offers totally 3.5A current.
- 4. If only use one channel DC output, please connect to Primary output socket.



### **Specifications**

Power input	100~240VAC,50/60Hz
Charging output	DC 7V-8.4V,1.8A×2
Adapting output	DC 8.4V,3.5A in total
Power consumption	Max 50W
Dimension	136×110×47mm
Mass	360g